



# PSM Manual & Hydraulic Quick Couplers



Hydraulic Multi-Pin Grabber Coupler  
(Shown coupling to bucket)




## HYDRAULIC PIN GRABBER COUPLER

An industry favorite, the Hydraulic Pin Grabber Coupler allows an operator to exchange a variety of attachments quickly. User friendly, the Hydraulic Pin Grabber Coupler will save time, material, and money.

## MANUAL PIN GRABBER

A Manual Pin Grabber allows an operator to change attachments in a matter of minutes. By simply using a wrench a coupler can be freed from one existing attachment and be put on another.



Hydraulic Wedge Coupler  
(Open Position)

Hydraulic Wedge Coupler  
(Locked Position)

Manual Wedge Bar  
(Locking Bar)

## SERIES II HYDRAULIC WEDGE COUPLER

A PSM Series II Hydraulic Wedge Coupler gives you all of the versatility you need to change between attachments without losing any breakout force. This coupler provides an exceptional coupler-attachment fit because of our unique “wear compensating system.” With this design, the spring-loaded hydraulic release system continually tightens the coupler. This process allows the operator to easily and quickly interchange attachments without ever leaving their cab. Attachments with the Series II coupler system may be interchangeable between various makes and models of excavators of the same class.

## PATENTED SERIES II MANUAL WEDGE COUPLER

The PSM Wedge Coupler provides an exceptional coupler-attachment fit because of our unique “wear compensating system.” This system allows an operator to “synch” out any extra room that exists between your wedge bar and the hooks on your bucket. In this process, the spring loaded wedge bar continually “synches” the coupler into the quick coupler lugging to limit the overall wear and maintenance. Attachments with the Series II coupler system may be interchangeable between various makes and models of excavators of the same class.